



# Metallics

## Oil Alert

*Never run out of oil again!*



**[CONTRACTOR APPROVED]**



— Receiver

Place up to 150'  
from transmitter.



— Transmitter



— Oil gauge

Place the transmitter over your oil gauge and align to the level that you want the alarm to sound at.

When your oil gauge reaches this arrow on the transmitter, the Oil Alert sends a signal to the receiver letting you know you are low on oil.

PART#	UPC#	DESCRIPTION	QTY/ PKG	SUG. TRADE LIST / PKG
OAG1	51385	Oil Alert Gauge Receiver & Transmitter	1	\$131.25/E

“Growth Through Innovation”

### Metallics

229 Cross Street, Bristol, CT 06010  
Tel 800-243-8272 • Fax 800-831-9358  
Email sales@metallicsonline.com

[www.metallicsonline.com](http://www.metallicsonline.com)